



PEN-SHAPED THERMOMETER



Operating Instructions

INSTRUMENT OPERATION - Pull out the battery insulation tag on first use. The instrument is switched on by pressing any function button located on the front of the thermometer. Apply the tip of the probe to the substance or medium to be measured. The instrument reading may take a few seconds to stabilise, depending on the nature of the measurement. The thermometer will automatically turn off after 10 minutes.


°C/°F - Press the °C/°F button to select the temperature scale required. The temperature scale chosen will be retained after automatically turning off.

HOLD - When the Hold function is selected, 'C' will flash to indicate the mode. Press the HOLD button to retain the display reading, press the HOLD button again to resume taking temperature. **Please note:** once HOLD is selected the unit will not automatically turn off.

BATTERY REPLACEMENT - Replace the battery by unscrewing the cover screw and flipping the battery cover up, replace the battery and flip the cover down and tighten the screw.

BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



EMC/RFI - Instrument performance may be affected if operated within a high frequency radio field, such as near a mobile phone, or if subjected to an electrostatic shock.

GUARANTEE - This instrument carries a two-year guarantee against defects in either components or workman-ship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. This guarantee does not apply to probes, where a six-month period is offered. The product guarantee does not cover damage caused by fair wear and tear, ab-normal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etiltd.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.



Manufactured by
Electronic Temperature Instruments Ltd
Worthing · West Sussex · BN14 8HQ
01903 202151 · sales@etiltd.com · etiltd.com



810-260 WEB/15.09.25